


All models

Tightening torque	Nm	(kpm)
Locking bolts for attaching steering box to frame	70–80	(7–8)



2 Fixing bolts for steering box

- Check the three hexagon and/or locking bolts for tight fit and retighten if necessary.

Note

To check the torque of locking bolts they must not be loosened.
If the tightening torque is below the rated torque the locking bolts must be retightened accordingly.